

YEDI HOUSEWARE 2QT AIR FRYER

Instruction Manual



Cautions :


- Please carefully read the instruction manual, before use the product. Keep the manual for reference in future;
- The product contains electronic elements and heating elements. Do not put the main housing in water.
- Do not cover the air inlet and outlet while operating.
- Do not fill oil in the basket or drawer, otherwise it may cause fire
- High temperature air will flow out through the outlet during the product working process. Please keep a safe distance of at least 6 inches. Do not put hands and/or faces close to the outlet.

Warning:

- Do not damage, strongly pull or twist the power cord, use it carry heavy loads, or transform it, to avoid electric shock, fire and other accidents. Damaged power cord must be repaired by manufacturer, maintenance department and other similar professional maintenance staff ;
- Please do not plug and unplug with wet hands, otherwise, easily cause electric shock ;
- Keep the product away from children to avoid scald, electric shock and/or other damages;
- Do not place the product on or near the flammable or explosive material, such as tablecloths, curtains and others, to avoid fire hazard;
- When using this appliance please make sure it is at least 6 inches away from the wall or any objects.
- The appliances are not intended to be operated by means of an external timer of separate remote-control system
- This appliance is intended for household use only. It is not meant to be used outside.
- This appliance can be used by children aged from 8 years and above if they are supervised and provided instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

Product Structure Diagram:

1. Handlebar
2. Fry basket
- 2b. Fry tray
3. Air inlet
4. Heating Indicator lamps
5. Timer (0~30min)
6. Temperature controller (180°F ~400°F)
7. Air outlet
8. Power cable



Before First Use:

Thoroughly wash the basket and tray in warm soapy water and wipe down the inside with a wet cloth, and then run at 400F for 5 minutes before first use. You may detect a slight smell and/or smoke. Don't worry this is normal. Then wash the basket and tray again, wipe down the inside again, and you are ready to use your Yedi!

Instruction:

1. Make sure the fry tray is inserted into the bottom of the fry basket.
2. Insert power cable into the earthed power socket.
3. Turn the Temperature Controller to desired temperature
4. Turn the Timer to 3 minutes for preheating. Preheating temp should be set to your desired cooking temperature.
5. When preheating is finished carefully pull the fry basket out from the appliance, place the food/ingredients inside the fry basket (Attention: do not exceed the maximum line); Put the fry basket back into the product.
6. Set the timer to the desired cooking time;
7. When you hear the ready bell, cooking has finished, and the food is ready to serve. Please pull the fry basket out, place it on a heat resistant material and carefully transfer the food to serving dishes.

(Note: For better cooking result, turn over the ingredients by shaking the basket in the middle of cooking process or stir ingredients with tongs.)

Care and Maintenance

1. Please unplug the power cord and let it cool before cleaning products.
2. Clean you air fryer after every use.
3. Use warm water, a small amount of dish soap and a soft cloth or soft sponge to gently clean the inside of the fry basket.
4. Do no ever place the power cord or the whole product into water.
5. Please store the air fryer in a cool and dry place.

Technical Specifications:

1. Rated Voltage: 120V
2. Rated frequency: 60Hz
3. Rated power: 1000W
4. Fry basket capacity: 1.8L
5. Net weight : 2.45KGS
6. Product Size: 210*268*289mm

Troubleshooting:

Problem	Possible Cause	Solution
Does not work	<ul style="list-style-type: none"> ● Power cord has not been inserted into the power socket 	<ul style="list-style-type: none"> ● Closely insert the power cord into the grounded power socket.
	<ul style="list-style-type: none"> ● Did not set the timer 	<ul style="list-style-type: none"> ● Set the timer to desired cooking time and power on.
Food is rare when time out	<ul style="list-style-type: none"> ● Too much food in the basket 	<ul style="list-style-type: none"> ● Fry food in turns
	<ul style="list-style-type: none"> ● Temperature set is too low 	<ul style="list-style-type: none"> ● Set to an appropriate temperature, re-fry food.
	<ul style="list-style-type: none"> ● Cooking time is short 	<ul style="list-style-type: none"> ● Set an appropriate cooking time, re-fry food.
Did not fry food evenly	<ul style="list-style-type: none"> ● Some type of food material should be shaking in middle of cooking time 	<ul style="list-style-type: none"> ● In the middle of cooking process, pull the drawer out and shake it for separate the overlapped food material, then push the drawer back to continue.
Fried food is not crisp	<ul style="list-style-type: none"> ● Some food materials have to be fried with oil 	<ul style="list-style-type: none"> ● Plush a thin layer of oil on the surface of the food material first, then start to fry them.
Cannot smoothly push the drawer back to product	<ul style="list-style-type: none"> ● The drawer with too many food materials is too heavy 	<ul style="list-style-type: none"> ● The food material in the basket can not exceed the max. line.
	<ul style="list-style-type: none"> ● The basket is not correctly placed in the drawer. 	<ul style="list-style-type: none"> ● Press the basket into the drawer.
	<ul style="list-style-type: none"> ● Handlebar stuck 	<ul style="list-style-type: none"> ● Place the handlebar in horizontal position.
Smoking	<ul style="list-style-type: none"> ● Frying oily food 	<ul style="list-style-type: none"> ● Normal phenomenon.
	<ul style="list-style-type: none"> ● Fryer contain oil from last use 	<ul style="list-style-type: none"> ● Please clean the drawer and basket after use.

Yedi®

H O U S E W A R E

AIR FRYERS | PRESSURE COOKERS | AIR FRYER OVENS | SOUS VIDES



“The YEDI HOUSEWARE TOTAL PACKAGE AIR FRYER, our top pick thanks to its large capacity and built-in smart programs that make perfect cooking incredibly easy.”
- BUSINESS INSIDER -



“The YEDI TOTAL PACKAGE PRESSURE COOKER, selected to the Oprah’s Favorite Things List.”
- O, THE OPRAH MAGAZINE -

 @yedihouseware